Cadillac bls 2007 manual

I'm not robot!











```
Page 1 460 OM MY09.book Page 1 Wednesday, April 2, 2008 10:32 AM Owner's Manual Cadillac BLS Safety Locks and car alarm Instruments and controls Interior equipment Starting and driving 123 Car care 173 Technical data 235 Index 255 © Copyright General Motors Corporation 2008... Page 2 Cadillac. Since the policy at Cadillac is one of con-
not followed. The specifications, design particulars and illus- tinual improvement, we retain the right to trations included in the manual are not binding. 460_OM_MY09.book Page 3 Wednesday, April 2, 2008 10:32 AM Instrument panel, LHD Fuel gauge
                                                                                                                                                                                                                                                                                                                                                                                                        Temperature gauge
                                                                                                                                                                                                                                                                                                                                                                                                                                                   Warning and
indicator lights
                           Rev counter
                                                                    Settings
                                                                                                           Milometer and trip meter
                                                                                                                                                       DIC
                                                                                                                                                                                            Direction indicators
                                                                                                                                                                                                                                 Cruise control
                                                                                                                                                                                                                                                                   144 Dip switch
                                                                                                                                                                                                                                                                                                          Changing wiper blades
                                                                                                                                                                                                                                                                                                                                                                                . 460 OM MY09.book Page 4 Wednesday, April 2, 2008 10:32 AM
Instrument panel, RHD Fuel gauge
                                                                       Speedometer
                                                                                                              Temperature gauge
                                                                                                                                                         Settings
                                                                                                                                                                                                Warning and indicator lights
                                                                                                                                                                                                                                                                                  Rev counter
                                                                                                                                                                                                                                                                                                                          Milometer and trip meter
                                                                                                                                                                                                                                                                                                                                                                       Changing wiper blades
                                                                                                                                                                                                                                                                                                                                                                                                          Wash/wipe
                                                                                                                                                                                                                                                                                                                                                                                                                                           Direction indicators
                                                                             144... Page 5 460 OM MY09.book Page 5 Wednesday, April 2, 2008 10:32 AM Exterior Maximum loads
                                                                                                                                                                                                                                                                               Mounting holes for roof carriers Washing the engine bay
         Washer fluid
                                           Cruise control
                                                                                                                                                                                                                                        Bonnet
                                                                                                                                                                                                                                                                                                                                                                         Roof load
                                                                                                                                                                                                                                                                                                                                                                                                                                                230 Touching up
                   230 Anti-corrosion treatment 231 Front lights
                                                                                                                                         232 Direction indicators
                                                                                                                                                                                                                    102... Page 6 460 OM MY09.book Page 6 Wednesday, April 2, 2008 10:32 AM Interior Interior rear view mirror
paintwork
                                                                                                       Service programme
                                                                                                                                                                                   Sunroof
                                                                                                                                                                                                                                                                                                                                                                                  Interior lighting: changing bulbs
                                                                                                                                                                                                                                                                                                                                                                                                                                 Vanity mirror
                                                                                                                                                                                                                  Steering wheel adjustment Child seats
                      Interior light switches
                                                                                                           Sunroof
                                                                                                                                                                                                                                                                                        Seat belts
                                                                                                                                                                                                                                                                                                                                                         Child safety locks
                                                                                                                                                                                                                                                                                                                                                                                            ... Page 7 460_OM_MY09.book Page 7 Wednesday, April 2,
2008 10:32 AM Engine bay, Engine: description
                                                                                                                                                                             Driving in hot climates
                                                                              Coolant: checking/topping-up
                                                                                                                          182 Engine oil: topping up
                                                                                                                                                                                                                        162 turbo petrol engine Engine: technical data
                                                                                                                                                                                                                                                                                                                                          238 Important considerations for Temperature gauge
                                                                                                                                                                                                                                                                                                   Radiator
Vehicle identification... Page 8 460 OM MY09.book Page 8 Wednesday, April 2, 2008 10:32 AM Engine bay, Engine: description
                                                                                                                                                                                       Cooling system, coolant capacity Engine oil: topping up
                                                                                                                                                                                                                                                                                                                         petrol engine V6 Engine: technical data
                                                                                                                                                                                                                                                                                Coolant: checking/topping-up
                                                                                                                                                                                                                                                                                                                                                                                              Driving in hot climates
                                                                                                                                                                                                                                                                                                                                                                                                                                           Important
considerations for Temperature gauge
                                                                                                                                           185... Page 9 460 OM MY09.book Page 9 Wednesday, April 2, 2008 10:32 AM Engine bay, Engine: description
                                                                                                                                                                                                                                                                                                                                                                                                                                   Driving in hot climates
                                                                                                                                                                                                                                                                                                           Coolant: checking/topping-up ____ 182 diesel engine TiD 3 Engine oil: topping up
                                                                  driving
                                                                                                         Power steering
              162 Engine: technical data
                                                                                                      238 Important considerations for Temperature gauge
                                                                                                                                                                                                                                 Vehicle identification... Page 10 460 OM MY09.book Page 10 Wednesday, April 2, 2008 10:32 AM Engine bay, Engine: description
                                                               Radiator
                                                                                                                                                                                                                                                                                                                                                                                                                            Coolant: checking/topping-up
182 diesel engine, TTiD 3 Engine oil: topping up
                                                                             Driving in hot climates
                                                                                                                        162 Engine: technical data
                                                                                                                                                                                                                 238 Important considerations for Temperature gauge
                                                                                                                                                                                                                                                                                                      driving
                                                                                                                                                                                                                                                                                                                                            Vehicle identification... 460 OM MY09.book Page 11 Wednesday, April 2, 2008 10:32 AM
Warning labels Fuel-driven heater Switch off the parking heater before Radiator fan may start at any time. A/C system Refrigerant at high pressure. Do not loosen or remove the A/C system fittings before discharging the A/C system. Page 12 • Only use the jack on a level and firm surface. • Do not crawl under a car raised by
a jack; use axle stands. • There must no one inside the car. We recommend that you contact an authorised Cadillac workshop for Xenon bulb replacement 3. Page 13 460_OM_MY09.book Page 13 Wednesday, April 2, 2008 10:32 AM Example of symbols that can be found in your car No sparks, Windscreen Coolant flames or Buckle up Headlights
Radiator fan wipers temperature smoking Refer to the Direction Windscreen No charge to Owner's Airbag Fuel... Page 14 460 OM MY09.book Page 15 Wednesday, April 2, 2008 10:32 AM Safety Seat belts
                                                                                            3 Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories). 460 OM MY09.book Page 16 Wednesday, April 2, 2008 10:32 AM Safety Seat belts Three-point inertia reel seat belts are pro-vided for all
seats. Research has established that it is equally WARNING as dangerous for rear seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat belts as for front seat passengers not to wear their seat passen
The diagonal strap must be as far WARNING in on the shoulder as possible. Page 18 460 OM MY09.book Page 18 Wednesday, April 2, 2008 10:32 AM Safety Buckling up Press the red button to release the belt Front belt guide Front seat belts Belt guide Position the diagonal strap as far in on the shoulder as possible. Fasten the belt by smoothly
pulling out the The belt guide for the front seat belts can be Press the red button on the buckle to... Page 19 We recommend that you contact an authorised Cadillac workshop. The seat belts of the front seats have pre-
Expectant mothers tensioners and force limiters. Page 20 460 OM MY09.book Page 20 Wednesday, April 2, 2008 10:32 AM Safety Seat belts, rear seat WARNING • Take care that the belt does not become trapped when the backrest is folded down or raised, see page 110. • If you must place an item of luggage on a seat, ensure that it is secured
properly with the seat belt. 460 OM MY09.book Page 21 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 22 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat in the following order: 1 Height WARNING 2 Legroom Only adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 22 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 22 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 22 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 22 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 20 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary. Page 22 460 OM MY09.book Page 20 Wednesday, April 2, 2008 10:32 AM Safety Seats We recommend that you adjust the driver's seat when the car 3 Backrest rake angle is stationary.
2008 10:32 AM Safety Legroom adjustment Adjusting the backrest Lumbar support adjustment Lumbar support 3 Legroom adjustment Backrest rake angle Adjust the firmness of the lumbar support by turning the wheel. WARNING WARNING Check that the seat is locked in its new The backrest should be upright for position. Page 23
460 OM MY09.book Page 23 Wednesday, April 2, 2008 10:32 AM Safety Electrically adjustable front seats 3 WARNING • The seats are actuated by powerful motors. Make sure that nothing can be trapped or damaged when adjustable front seats are actuated by powerful motors. Make sure that nothing can be trapped or damaged when adjustable front seats.
460_OM_MY09.book Page 24 Wednesday, April 2, 2008 10:32 AM Safety Adjusting the backrest should be upright for The legroom of the
electrically operated... Page 25 460 OM MY09.book Page 25 Wednesday, April 2, 2008 10:32 AM Safety When the ignition is ON, all seat settings can be adjusted for up to 20 minutes. 460 OM MY09.book Page 26
Wednesday, April 2, 2008 10:32 AM Safety Head restraints WARNING • Adjust the head restraint to f the seats that are occupied, 460 OM MY09, book Page 27 Wednesday, April 2, 2008 10:32 AM Safety
Child safety WARNING WARNING WARNING WARNING of in the luggage compartment of in the luggage com
equipment must be standard 3-point seat belt. adapted to the size of the child. Page 29 460 OM MY09.book Page 29 Wednesday, April 2, 2008 10:32 AM Safety Rear seat - fitting a child seat must be attached to the attachment points that are found under the driver and passenger seats (see
illustra- tion). Page 30 460 OM MY09.book Page 31 Wednesday, April 2, 2008 10:32 AM Safety Cadillac recommends that child seats 3 be placed in the rear centre rear (age) passenger seat... Page 31 460 OM MY09.book Page 31 Wednesday, April 2, 2008 10:32 AM
Safety Child seats 3, approved as per ECE R44.03 Weight (age) Height Up to 10 kg Child Seat (up to approx. with infant insert 9 months) Up to 13 kg Child Seat (up to approx. Page 32 460_OM_MY09.book Page 32 Wednesday, April 2, 2008 10:32 AM Safety ISOFIX To facilitate fitting a child seat, your car has ISOFIX attachment points. ISOFIX is a
car industry standard for the fitting of child seats. There are ISOFIX attachment points in the outer rear seats. Page 33 5 Tighten the tether so that the back of the sult your Cadillac dealer. child restraint is pressed hard against The car is provided with three top tether the backrest. 460 OM MY09.book Page 34 Wednesday, April 2, 2008 10:32 AM
Safety Airbag Airbag system components Note: The sensor reacts differently depending • Airbag in steering wheel. on whether or not the front seat belts on the • Airbag in front of front passenger seat. driver's and passenger sides are used. Page 35 460 OM MY09.book Page 35 Wednesday, April 2, 2008 10:32 AM Safety If the impact sensors
 register forces corre- sponding to a high speed collision (airbag stage II activated), the inflatable curtains will also be triggered. See page 40. If a fault arises in the airbag system during a journey, the airbag warning lamp on the main instrument panel will come on and the DIC will display:... Page 36 460 OM MY09.book Page 36 Wednesday, April 2
2008 10:32 AM Safety Airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surfaces marked as 1 Steering wheel with integral airbag system Accessories and other equipment must not be fitted to the surface of th
by the chemical shop. If the airbag lamp is illuminated, reaction that inflates the airbag in Front passenger seat • Keep your feet on the floor - never put a front-end collision The system is the same as that used on the feet up on
the fascia, on the seat or out driver's side. • Damage or wear to the upholstery or seams of the seat in the area near the side airbag must be immediately recti- fied. We recommend that you contact an authorised Cadillac workshop. Page 40 460 OM MY09.book Page 40 Wednesday, April 2, 2008 10:32 AM Safety • Do not position a sun visor or similar
in the area that would be filled by the inflatable curtain. • Do not attach anything to the car's headlining, roof pillars or side panels as this could prevent the side-impact protection from providing the intended protection. Page 41 The car must be checked trical circuitry. immediately. We recommend that you • During any welding, both battery contact
an authorised Cadillac workshop. cables must be disconnected and cov- See page 65. ered over. Prohibited seating position Servicing the airbag system •... Page 42 What won't trigger the airbag system will not be activated in all pant
i.e. square on from the front. If the front-end collisions. Page 43 We recommend your skin as it can cause irritation, consult a only the noise of the collision itself. Page 44 460 OM MY09.book Page 44 Wednesday, April 2, 2008 10:32 AM
Safety (This page has been left blank.) 460 OM MY09 book Page 45 Wednesday. April 2, 2008 10:32 AM Locks and car alarm Locks and car alarm Doors
                                                                                                                                                                                                                            Locks
                                                                                                                                                                                                                                                         Car alarm 3
                                                                                                                                                                                                                                                                                        Opening the fuel filler flap manually 3 3 Asterisk means: equipment not fitted in all cars (can depend on model variant, engine
variant, market specification, options or accessories). Page 46 If one is lost, a replacement should be manual as the remote control is programmed into the car, the lost one will be deprogrammed automatically. Page 47
(option for cars without car alarm, we recommend that you • Warm the remote control in your contact an authorised Cadillac workshop), hands for a couple of minutes if it has see page 57. become very cold to prevent malfunc- tion. Page 48 460 OM MY09.book Page 48 Wednesday, April 2, 2008 10:32 AM Locks and car alarm TSL locking 3
Locking/unlocking the car Remote unlocking the car Remote unlocking (Theft Security Lock) Pressing the button once - unlocks all TSL locking means that the doors can doors, the fuel filler flap and the boot lid. WARNING only be unlocked with the remote control. Page 49 460 OM MY09, book Page 49 Wednesday, April 2, 2008 10:32 AM Locks and car alarm Intermittent
malfunctioning If remote unlocking should fail to work Equipment in the vicinity of the car that uses 1 Remove the traditional key from the remote control by pressing the emblem may cause interference to the remote control of the remote control to the remote control of the car that uses 1 Remove the traditional key from the traditional key from
2008 10:32 AM Locks and car alarm Locking a car with flat battery Boot lid The steering wheel lock requires sufficient The boot lid is unlocked along with the battery voltage to lock and unlock. If the car doors. 460 OM MY09.book Page 51 Wednesday, April 2, 2008 10:32 AM Locks and car alarm Locking the car with flat battery voltage to lock and unlock. If the car doors. 460 OM MY09.book Page 51 Wednesday, April 2, 2008 10:32 AM Locks and car alarm Locking the car with flat battery voltage to lock and unlock.
locks renders this switch inoperative. The rear doors are equipped with child • If you are inside the car and lock the car safety locks that are operated by means with the remote control, TSL will be acti- of a catch adjacent to the door lock. Page 52 WARNING temperatures and good service life, we grammed. We recommend that you contact
recommend the use of a Sony or Panasonic an authorised Cadillac workshop, see Keep the battery and other small compo- CR2032, 3V lithium battery, page 248, nents of the remote control out of reach of The battery should last for about 4 years of children. Page 53 460 OM MY09, book Page 53 Wednesday, April 2, 2008 10:32 AM Locks and car
alarm 3 Change the battery. Insert it in same way as the old battery, with the positive (+) side facing down. 4 Fit and press together the two halves of the remote control until you hear several clicks. WARNING Each time you remove the remote control until you hear several clicks.
child or animal in the car. In interlock is activated, the LED double- have the problem checked and rectified. The alarm is armed when all doors, the signals will be set off: Cadillac workshop, bonnet and the boot lid are closed and you • All direction indicators flash for 5 minutes, lock the car with the remote control, 460 OM MY09, book Page 56
Wednesday, April 2, 2008 10:32 AM Locks and car alarm Movement sensor 3 Switching off the alarm will be triggered (direction NOTICE The movement sensor monitors the cabin. indicators flashing and siren sounding) it The alarm will be triggered if a window Cadillac
workshop. The panic function is smashed and someone sticks in their 1 Select Settings using the steering makes it possible to trigger the alarm functions and indications can be reprogrammed. We recommend that you contact an authorised Cadillac workshop Tilt sensor The tilt sensor
trips the alarm if the angle of the for details of the possibilities. See also page 248. Page 59 Change of status of immobilizer Double-flashes for 3 s system, valid key inserted or Cadillac & Corvette Europe hereby declares that the original equipment used removed from ignition switch. in the remote control, door locks and alarm, as well as the decoding
equip- ment of the immobilizer system, fulfils the basic requirements stipulated in R&TTE, Directive 1999/5/EC of the European Parliament and of the Council... Page 60 Lift up the screws and press them out of their keys. The fuel filler flap can now be opened as usual. Contact a workshop to have the fault reme- died. We recommend that you contact
a Cadillac workshop. 460 OM MY09.book Page 61 Wednesday, April 2, 2008 10:32 AM Instruments and controls Instruments and controls Warning and indicator lights
                                                                                                                                                                                                                                              Instruments
                                                                                                                                                                                                                                                                             DIC (Driver Information Centre)
                                                                                                                                                                                                                                                                                                                                          Switches
                                                                                                                                                                                                                                                                                                                                                                        Wipers and washers Automatic climate control (ACC) 3
Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories). 460 OM MY09.book Page 62 Wednesday, April 2, 2008 10:32 AM Instruments and controls Main instrument panel Warning and indicator lights The warnings and indications that can be shown depend on the
engine variant and equipment level. ABS brakes warning light This warning light the auti-lock brake system. Page 63 We recommend engine and check the oil level. See that you contact an authorised Cadillac If the fault is not rectified, more serious page 180. faults may arise affecting driveability. Page 64 The
following message appears in DIC at to the nearest workshop to have the brake fluid level low. The brake fluid level low. The brake fluid level low to the nearest workshop to have the same time: system provides Electronic This lamp indicates when the rear fog light Brakeforce Distribution (EBD). Page 65 We
Airbag malfunction. WARNING recommend that you contact an authorised Contact service. Cadillac workshop. Refer to Brake warning • Always apply the handbrake on light on page 64, ABS brakes warning parking. light on page 62 and TCS OFF or WARNING ®... Page 66 460 OM MY09.book Page 66 Wednesday, April 2, 2008 10:32 AM
Instruments and controls ® Cruise control indicator TCS or StabiliTrak light 3 indicator light 3 Fuel-low indicator light 4 fuel-low indicator light 4 fuel-low indicator light 5 fuel-low indicator light 5 fuel-low indicator light 5 fuel-low indicator light 5 fuel-low indicator light 6 fuel-low indicator light 8 fuel-
contact an author- ised Cadillac workshop. Indicator, glow pluq See also Traction Control System (TCS) on (cars with diesel engine) 8... Page 68 460 OM MY09.book Page 68 Wednesday, April 2, 2008 10:32 AM Instruments and controls Automatic tyre pressure monitoring 3 The lamp illuminates if the tyre pressure in one or more tyres is too low or a
fault has arisen in the tyre pressure system, see page 214. 460 OM MY09.book Page 69 Wednesday, April 2, 2008 10:32 AM Instruments and controls Instruments and controls Instruments Speedometer Temperature gauge shows the temperature gauge The speedometer displays the spe
The needle should be Rev counter mation about vehicle speed from the ABS's in the middle of the scale when the engine... 460 OM MY09.book Page 70 Wednesday, April 2, 2008 10:32 AM Instruments and controls NOTICE WARNING If the needle goes into the red zone, Never remove the expansion tank filler despite these measures, stop the car in
a cap completely while the engine is warm, suitable place and allow the engine to Slacken the cap carefully, 460 OM MY09, book Page 71 Wednesday, April 2, 2008 10:32 AM Instruments and controls DIC (Driver Information Milometer and trip meter and trip meter displays the distance tray-Centre) elled in miles, and the trip meter in miles and
tenths of miles. It lights when the car DIC displays various types of information: is unlocked or when the door is opened milometer, trip meter, warnings, indications,... Page 72 460 OM MY09.book Page 72 Wednesday, April 2, 2008 10:32 AM Instruments and controls Trip computer functions in DIC Outside temperature Dist Distance to destinations.
Function can also be used as a trip meter WARNING WARNING WARNING Speed Ø Average speed Bear in mind that ice can develop on the Trip computer settings should be made SPD W Speed warning... Page 73 460 OM MY09.book Page 73 Wednesday, April 2, 2008 10:32 AM Instruments and controls Setting values Using DIST as a trip meter Resetting the
trip computer 1 Select the function using the steering 1 Select Dist using the steering wheel 1 Press and hold the CLR buttons, ... Page 74 460 OM MY09.book Page 74 Wednesday, April 2, 2008 10:32 AM Instruments and controls Speed warning Calculating the arrival time
Calculating the arrival time if a specified average speed is maintained This value is preset to 55 mph (90 km/h). (When will I arrive if I know how far I have... 460 OM MY09.book Page 75 Wednesday, April 2, 2008 10:32 AM Instruments and controls Settings Park
Assistance, page 155. Settings Parameters such as language and unit of Block Heater, page 263. measure are selected via this heading. 1 Select Settings using the steering MANUAL START Alarm Clock, page 76. Page 76 The percentage refers, then, to the other service type. MAIN Main services are carried out at specific meter settings. This interval
varies depending on market and engine variant. Contact a workshop for more information. We recommend that you contact an authorised Cadillac workshop. Page 77 460 OM MY09.book Page 77 Wednesday, April 2, 2008 10:32 AM Instruments and controls Resetting the service check Analogue clock INTERMEDIATE Reset the service check as
follows: The analogue clock is set manually. It is not The intermediate service, on the linked to the clock in the radio display. 1 Turn the remote controls Switches Lights off The car's exterior lights are off. The headlights can be flashed. Position
lights The position lights can be turned on irre- Light switches Dip switch spective of the position of the ignition switch. 460 OM MY09.book Page 79 Wednesday, April 2, 2008 10:32 AM Instruments and controls Follow-me-home lights to
remain on for about 30 seconds after the driver's door has been closed. 460 OM MY09.book Page 80 Wednesday, April 2, 2008 10:32 AM Instruments and controls Cars with Xenon headlights have an auto- matic headlight levelling system 3. This Posi-
Number of Load... 460 OM MY09.book Page 81 Wednesday, April 2, 2008 10:32 AM Instruments and controls WARNING In poor visibility, avoid following the tail lights of the vehicle in front. There is a risk of driving too close. If the vehicle brakes suddenly, you may be unable to avoid a collision and therefore risk injury to your-self and others.
460 OM MY09.book Page 82 Wednesday, April 2, 2008 10:32 AM Instruments and controls Warning triangle is stowed on the simultaneously, the most important function luggage compartment floor. 460 OM MY09.book Page 83 Wednesday, April 2, 2008 10:32 AM Instruments and controls Warning triangle is stowed on the simultaneously, the most important function luggage compartment floor. 460 OM MY09.book Page 83 Wednesday, April 2, 2008 10:32 AM Instruments and controls Warning triangle is stowed on the simultaneously, the most important function luggage compartment floor.
2008 10:32 AM Instruments and controls Wipers and washers Washers Activate the washers by pulling the stalk Windscreen wipers switch towards the steering wheel. When the washers are operated, the wipers Position 1 is a spring-loaded position that will make 3, 4 or 5 sweeps, depending on will produce a single sweep of the wipers. Page 84
460_OM_MY09.book Page 84 Wednesday, April 2, 2008 10:32 AM Instruments and controls Rain sensor off the ignition is ON to avoid personal injury when clearing snow and ice from the windscreen. NOTICE Turn the rain sensor off before washing the car in an automatic car wash, to avoid Control for setting
intermittent wiper delay. Page 85 460 OM MY09.book Page 85 Wednesday, April 2, 2008 10:32 AM Instruments and controls Adjusted in Settings. If you increase the sensitivity, the wipers will make one sweep The sensor is set to high sensitivity.
Page 86 460 OM MY09.book Page 86 Wednesday, April 2, 2008 10:32 AM Instruments and controls Rear window washer jet is not adjustable. Changing wiper blades, see page 188. To obtain: When the washer fluid level drops below 1 • a single sweep: move the control to posi- litre, the rear window washer is deactivated.
460 OM MY09.book Page 87 Wednesday, April 2, 2008 10:32 AM Instruments and controls Automatic Climate Control system (ACC) maintains the desired temperature inside the car, regardless of the outside temperature and weather conditions. The system will achieve the desired temperature in the quickest
possible way. Page 88 460 OM MY09.book Page 88 Wednesday, April 2, 2008 10:32 AM Instruments and controls The system has seven sensor. • Cabin temperature sensor. (located in the front floor vents).
Page 89 460 OM MY09.book Page 89 Wednesday, April 2, 2008 10:32 AM Instruments and controls Temperature closed to prevent warm air being distributed
turning the temperature control to the first zones:... 460 OM MY09.book Page 90 Wednesday, April 2, 2008 10:32 AM Instruments and controls Functions The rear window and door mirror heating is controlled manually. Manual settings are not affected by the system's automation. Deactivate the heating as soon as the rear window is Pressing AUTO
will cancel all manual settings. Page 91 460 OM MY09.book Page 91 Wednesday, April 2, 2008 10:32 AM Instruments and controls Air distribution One press: When the defroster is chosen manu- Defroster and floor vents ally, all the windows (except the rear side windows, where the air flow is off) are demisted by: •... Page 92 460 OM MY09.book
Page 92 Wednesday, April 2, 2008 10:32 AM Instruments and controls Initial settings in cold weather To start with, the system will also be distributed through the floor vents and the fan speed will be increased. Page 93 460 OM MY09.book
```

```
Page 93 Wednesday, April 2, 2008 10:32 AM Instruments and controls Formation of ice and mist in Calibrated automatically every 40th start (if the ignition has been off It is only in the most extreme conditions that The seat cushions and backrests of the front for
more than 2 hours) or if the battery has... Page 94 460 OM MY09.book Page 94 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 Wednesday, April 2, 2008 10:32 AM Instruments and controls (This page has been left blank) 460 OM MY09.book Page 95 OM MY09.
                                                                                                                                                  Storage compartments Luggage compartment _ 3 Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories). 460_OM_MY09.book Page 96 Wednesday, April
 2, 2008 10:32 AM Interior equipment Steering wheel adjustment WARNING Only adjust the steering wheel while the car is stationary so that you are not dis-tracted from the traffic. The height and reach of the steering wheel while the car is stationary so that you are not dis-tracted from the traffic. The height and reach of the steering wheel while the car is stationary so that you are not dis-tracted from the traffic.
 WARNING Bear in mind the pinch hazard when closing the side windows. Risk of serious or fatal injuries! • Always remove the remote control from the ignition switch when leaving the car. Page 98 460_OM_MY09.book Page 98 Wednesday, April 2, 2008 10:32 AM Interior equipment Comfort closing 3 To close Deactivating the rear window switches
WARNING WARNING in the driver's door deactivates the window switches in the rear doors. Take care when closing a window to Make sure no one gets caught. Page 99 Wednesday, April 2, 2008 10:32 AM Interior equipment If dirt, ice or
similar create so much resist- Calibration is performed as follows: ance that the pinch protection engages in 1 Close the doors. the front electric windows (the window cannot be closed), the pinch protection engages in 1 Close the doors. the front electric windows (the window cannot be closed), the pinch protection engages in 1 Close the doors. the front electric windows (the window cannot be closed), the pinch protection engages in 1 Close the doors.
mirrors Door mirrors To adjust The door mirrors are electrically adjustable and heated. The controls for adjustable and heated. The controls for adjustable and heated adoor mirror with the upper button. 460_OM_MY09.book Page 101 Wednesday, April 2, 2008 10:32 AM Interior equipment Interior rear view mirror with auto dimming 3 Press button 2 to
activate auto dimming. The rear view mirror has two sensors: one forward-facing sensor detects whether it is dark outside. 460 OM MY09.book Page 102 Wednesday, April 2, 2008 10:32 AM Interior equipment Sunroof 3 WARNING Bear in mind the pinch hazard when closing the electric sunroof. Risk
of serious or fatal injuries! • Always remove the remote control from the ignition switch when you leave the car. Page 103 460 OM MY09.book Page 103 Wednesday, April 2, 2008 10:32 AM Interior equipment Comfort opening of windows and the
sunroof 3. • To open - press the control up. WARNING Press and hold the unlocking button on the •... Page 104 460 OM MY09.book Page 104 Wednesday, April 2, 2008 10:32 AM Interior equipment Pinch protection. The sunroof is equipped with pinch
protec- tion. This is activated if something gets trapped when the sunroof is being closed. 460_OM_MY09.book Page 105 Wednesday, April 2, 2008 10:32 AM Interior lighting on continuously Interior lighting When
the switch is in the mid-position (door- If a door is left open, the light switch is in activated), the interior equipment Can holder 3 WARNING • The can holder should not be used to hold cups made of china or
glass as these can cause personal injury in the event of a collision. •... 460 OM MY09.book Page 107 Wednesday, April 2, 2008 10:32 AM Interior equipment Ashtray by opening it and then lifting it straight up. Refit the ashtray by sliding straight in
 460 OM MY09.book Page 108 Wednesday, April 2, 2008 10:32 AM Interior equipment Storage compartments WARNING The glove compartment must be closed while travelling. This particularly applies if the car has a passenger airbag. An open glove compartment door could cause per- sonal injury in the event of a collision. Page 109
460 OM MY09.book Page 109 Wednesday, April 2, 2008 10:32 AM Interior equipment Open the glove compartment with the Sliding cover in glove compartment to Storage pocket on front edge of seat button on the left of the moulding. admit cold air . 460 OM MY09.book Page 110 Wednesday, April 2, 2008 10:32 AM Interior equipment Luggage
compartment Folding down the rear seat backrest, Sedan WARNING • Never driver the car if the backrest is not correctly locked into position as this increases the risk of personal injury in the event of heavy braking or a collision. 460_OM_MY09.book Page 111 Wednesday, April 2, 2008 10:32 AM Interior equipment For greater flexibility, the rear
seat is split so that the narrow and the wide part can be folded down separately. Next to the hinges in the luggage compartment are handles for unlocking the rear seat backrests. 460_OM_MY09.book Page 112 Wednesday, April 2, 2008 10:32 AM Interior equipment Luggage compartment lighting WARNING The luggage compartment lighting comes
on when the compartment is opened and goes out when it is closed. • Always secure the load firmly, for example using the middle seat belt. 460_OM_MY09.book Page 113 Wednesday, April 2, 2008 10:32 AM Interior equipment Emergency opening the narrow Securing loads section of the backrest, Sedan The narrow section of the backrest can be
WARNING opened in an emergency if the car is without electricity (not possible to open boot lid) and •... Page 114 460_OM_MY09.book Page 114 Wednesday, April 2, 2008 10:32 AM Interior equipment Cargo net 3 • If possible, avoid having the rear seat folded down when driving with a heavy load, because the anchoring possibili- WARNING ties are
restricted when the rear seat is in this position. Page 115 460 OM MY09.book Page 115 Wednesday, April 2, 2008 10:32 AM Interior equipment Tipping the rear seat down, Wagon WARNING • Never driver the car if the backrest is not correctly locked into position as this increases the risk of personal injury in the event of heavy braking or a
collision. Page 116 460_OM_MY09.book Page 116 Wednesday, April 2, 2008 10:32 AM Interior equipment Luggage compartment lighting On the two side trims is a light that is switched on and off when the WARNING luggage compartment lighting On the two side trims is a light that is switched on and off when the warming the luggage compartment lighting On the two side trims is a light that is switched on and off when the warming luggage compartment lighting On the two side trims is a light that is switched on and off when the warming luggage compartment lighting On the two side trims is a light that is switched on and off when the warming luggage compartment lighting On the two side trims is a light that is switched on and off when the warming luggage compartment luggage compartment lighting On the two side trims is a light that is switched on and off when the warming luggage compartment luggage compar
is left open, the lighting will be switched on top. Page 117 460_OM_MY09.book Page 117 Wednesday, April 2, 2008 10:32 AM Interior equipment Load-through hatch, Wagon WARNING • Always secure the load firmly, for example using the middle seat belt. This reduces the danger of personal injury resulting from the displacement of the load on hard
braking or in the event of a collision. Page 118 460 OM MY09.book Page 118 Wednesday, April 2, 2008 10:32 AM Interior equipment Load anchoring • Provide protection on sharp edges to prevent damage to the anchoring or in the event of a collision. Page 118 Wednesday, April 2, 2008 10:32 AM Interior equipment Load anchoring or in the event of a collision. Page 118 Wednesday, April 2, 2008 10:32 AM Interior equipment Load anchoring or in the event of a collision.
seat is far forward as possible in the luggage folded down. Page 119 460_OM_MY09.book Page 119 Wednesday, April 2, 2008 10:32 AM Interior equipment Cargo net 3 Cargo net, vertical, Wagon WARNING Fit the net behind the rear seat backrest. WARNING Fit the net behind the rear seat backrest. WARNING 1 Remove the rear cover panels in the • Match the speed and driving style roof. Page 120
460_OM_MY09.book Page 120 Wednesday, April 2, 2008 10:32 AM Interior equipment Attaching the cargo net to the roof Cargo net fitted in front anchorage eye Storing the cargo net storage When the cargo net is not in use it should be stored in the bag supplied. Page 121 460 OM MY09.book Page 121 Wednesday, April 2, 2008 10:32 AM Interior
equipment Cargo net, floor mounted, Wagon 1 Fold up the floor. Position the edges of the floor in the slots in the slots in the floor and secure the net's hooks in the floor and secure the net's hooks in the floor. Page 122 460 OM MY09.book Page 122 460 OM MY09.book Page 122 Wednesday, April 2, 2008 10:32 AM Interior equipment Cargo guard 3, Wagon NOTICE Do not
place any objects on the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage. To fit 1 1 Hold the cartridge so that the extended cargo guard. It is designed to shield against view and not for storage.
                                                                             Driving in cold climates _ Important considerations Driving in hot climates _ for driving
                                                                                                                                                                                                                  Towing a caravan or... 460 OM MY09.book Page 124 Wednesday, April 2, 2008 10:32 AM Starting and driving Ignition switch In cars with automatic transmission, the remote control can only
be removed when the selector lever is in position P. WARNING Position 2 • Always remove the remote control The position 2 • Always remove the remote control The position 3 Position 3 Position 4 The entire electrical system are operative.
system is operative. Do The starter motor cranks (automatic trans- not leave the remote control in this posi- mission: selector lever must be in P or N) tion when the engine is not running. 460_OM_MY09.book Page 126 Wednesday, April 2, 2008 10:32 AM Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Steering wheel lock If there is a fault that may affect the function Starting and driving Starting Starting and driving Starting and driving Starting Starting and driving Starting Start
the engine of the steering wheel lock, the following message will be displayed on the DIC: The steering wheel lock is electronic and is WARNING engaged when the remote control is with-... 460 OM MY09.book Page 127 Wednesday, April 2, 2008 10:32 AM Starting and driving Starting the engine Cars with automatic transmission Useful tips on
starting 1 The selector lever must be in the P or Avoid racing the engine or loading it heavily Petrol engine N position. Page 128 Wednesday, April 2, 2008 10:32 AM Starting in cold climates (diesel engines) At very low temperatures, you
may need to If the car is to be used in a cold climate for When the temperature is about 0 °C or run the starter motor for up to 60 seconds. • If the engine sounds strange there is a when it is idling. malfunction. We recommend that you 3 Boost pressure regulation.
is optimised for RON 95, 1 Starting and driving. Page 130 We recommend that you contact an "Engine malfunction (CHECK authorised Cadillac workshop. To ensure that the catalytic converter con- ENGINE)" indicator illuminates in the main tinues to function properly, and also to avoid... Page 131 • Never park the car in dry grass or on other
catalytic converter. We recommend that combustible material. The catalytic con- you contact an authorised Cadillac work- verter gets very hot and could therefore shop for advice. start a fire. Page 132 During town driving for example, the engine braking. This
• Use a genuine Cadillac exhaust is least noticeable during highway driving. system, which is designed to with- stand the temperature increase that... Only use fuel grades from a well-known oil For optimum performance we recommend: company. • RON 95 for 4-cyl. petrol engines. All Cadillac petrol engines can be driven WARNING • RON 98 for 2.8
 V6. on petrol with an octane rating between 91 RON and 98 RON (RON = Research •... Page 134 460 OM MY09.book Page 134 Wednesday, April 2, 2008 10:32 AM Starting and driving Cars adapted to run on E85 • When the engine is cold and the propor- (85% ethanol) tion of E85 in the fuel tank is large NOTICE (above 50%) engine torque is
limited in The fuel tank holds 61 litres. Page 135 460_OM_MY09.book Page 135 Wednesday, April 2, 2008 10:32 AM Starting and driving Cars with diesel engine 3 Refuelling Only use diesel fuel intended for vehicle use. Diesel engine 3 Refuelling Only use diesel fuel intended for vehicle use.
contact Do not run the starter motor for an unnec- standing in the car, in the luggage an authorised Cadillac workshop. essarily long time if there is no fuel in the compartment or any other surface tank. 460_OM_MY09.book Page 137 Wednesday, April 2, 2008 10:32 AM Starting and driving Running-in Manual gearbox Pistons, bores and bearings
need time to When changing gear, fully depress the bed in, to obtain uniform, wear-resistant sur- clutch pedal and then release it smoothly. It faces. 460 OM MY09.book Page 138 Wednesday, April 2, 2008 10:32 AM Starting and driving Automatic transmission 3 WARNING Indication of gear position on main instrument panel • Depress the brake
pedal when shifting the selector lever from P or N. Park Brake Shift Lock •... Page 139 460 OM MY09.book Page 139 Wednesday, April 2, 2008 10:32 AM Starting and driving Adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The adaptive gear change patterns Thermal transmission protection of the gearbox The
temperature of the transmission fluid driving conditions. Page 140 460 OM MY09.book Page 140 Wednesday, April 2, 2008 10:32 AM Starting and driving Lock-up Driving with a heavy load on hilly Descending hills roads The transmission's torque converter has a If the speed of the car increases while so-called lock-up function. This means that
descending a steep hill, despite the acceler- The transmission fluid can overheat when in gear, the torque converter is locked in,... Page 141 Check fuse 6 in the engine bay electrical centre. If the fuse is whole the battery may be flat. We recommend that you contact an authorised Cadillac workshop to have the problem checked and rectified. Page 142
460_OM_MY09.book Page 142 Wednesday, April 2, 2008 10:32 AM Starting and driving Selector positions You must press the brake pedal to move the selector lever from the is mechanically blocked. Page 143 460_OM_MY09.book
Page 143 Wednesday, April 2, 2008 10:32 AM Starting and driving Sentronic, manual gear selection Move the selector lever to the manual position (M) (to the left position D) to select gear manually. Select a higher gear by pressing the selector lever forward or a lower gear by pulling it back. Error messages If a fault occurs in the system, a fault
(Cruise Control system) message is shown in DIC. We recommend contacting an authorised Cadillac WARNING workshop. Do not use the cruise control system in wet or icy conditions, in dense traffic or on winding roads. Page 145 Wednesday, April 2, 2008 10:32 AM Starting and driving To set the speed Temporary
 increase in speed Accelerate, without shifting down (manual 1 Slide the switch to ON. gearbox), to exceed the set speed such as 2 Jog the control to SET/+ or SET/- when for overtaking and driving Braking ABS brakes WARNING It is good practice to try your brakes period-
 WARNING ically while driving. This is particularly The brake pressure required when the important when driving in heavy rain, on engine is off, such as when the car is on No ABS system can set aside the laws of roads with a lot of surface water, in snow or... Page 147 460 OM MY09.book Page 147 Wednesday, April 2, 2008 10:32 AM Starting and
driving The brake system provides Electronic Brakeforce Distribution (EBD). This distrib- utes the brake pressure between the front and rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load. 5% to the rear wheels, in such a way as to achieve optimum braking performance irrespective of the car's speed or load.
contact an authorised Cadillac work- How the system works instantaneously between the front and rear shop. wheels, depending on the driving condi- The Traction Control System (TCS) is tions. Page 149 460 OM MY09.book Page 149 Wednesday, April 2, 2008 10:32 AM Starting and driving so low that a lot of wheelspin can occur rap- TCS indicator
Turning the TCS off temporarily idly: When the remote control is turned to posi- The TCS is switched on automatically when •... 460_OM_MY09.book Page 150 Wednesday, April 2, 2008 10:32 AM Starting and driving ® StabiliTrak wheel speed, yaw angle rate, lateral accel- eration, steering wheel angle and brake pressure. Signals from these sensors
are Anti-skid system used to calculate the course of the vehicle, the driver's intentions and whether the WARNING ® ... Page 151 Contact service. ® ® when the StabiliTrak system is operative. NOTICE Chassis modifications, such as change of wheels, bumper or suspension, could ® affect the function of the StabiliTrak system. We recommend that you
contact an authorised Cadillac workshop before replacing chassis components. 460 OM MY09.book Page 152 Wednesday, April 2, 2008 10:32 AM Starting and driving Handbrake If conditions allow, it is best if the brake pedal is not depressed as little as necessary so as to stop the car WARNING rolling, when the handbrake is
 applied. 460 OM MY09.book Page 153 Wednesday, April 2, 2008 10:32 AM Starting and driving Parking on a hill NOTICE When parking on a steep hill, turn the front wheels so that they will be blocked by the WARNING Empty the car yourself and bear in mind: kerb if the car should move. 460 OM MY09.book Page 154 Wednesday, April 2,
2008 10:32 AM Starting and driving Laying the car up If the car is not going to be used for some time, e.g. three to four months, the following steps are recommended: • Drain the washer fluid reservoir and hoses. 460 OM MY09.book Page 155 Wednesday, April 2, 2008 10:32 AM Starting and driving Parking aid system 3 WARNING Responsibility
always lies with the driver when reversing. • The parking aid system can facilitate parking and reversing. • Bear in mind that small objects, such as a child lying on the ground, and/or narrow objects e.g. Page 156 460_OM_MY09.book Page 156 Wednesday, April 2, 2008 10:32 AM Starting and driving When the sensors detect an object within
 Reversing alongside a wall You can temporarily deactivate the parking the monitored area, pulses of sound (- - - - aid system as follows: If the distance between an object and a ) will be heard. Page 157 460 OM MY09.book Page 157 Wednesday, April 2, 2008 10:32 AM Starting and driving The system can be switched off in Settings. Explanation of
ON and OFF. 1 Select Settings using the steering wheel buttons, The parking aid system is activated 2 Hold the SET button depressed until a automatically when reverse is chime sounds. 460_OM_MY09.book Page 158 Wednesday, April 2, 2008 10:32 AM Starting and driving Economical motoring How to read the diagram (the following example
relates to petrol-engined cars): If fuel consumption with the engine at normal Factors affecting fuel temperature is 28 mpg (10 l/100 km), the consumption actual fuel consumption actual fuel consumption regularly. Increased
fuel consumption can indicate that something is wrong and that the car needs to be checked at a workshop. • For how to check the level of antifreeze in fuel filter and starve the engine of fuel. the engine coolant, see page 182. Page 161 We recommend that you
contact an author- has a manual gearbox, the best response is wheel arch liner at full lock. ised Cadillac workshop regarding approved to freewheel, which means declutching so snow chains. • Refer to the "Technical data" section... 3 Have the car's cooling system checked the temperature gauge falls, wait until a at a workshop. We recommend that
you normal temperature is shown (about in contact an authorised Cadillac Work- Always check the coolant level before the middle of the scale) before switching shop. (front) wheels can start to spin workshop has information on how the trical
socket then it is possible to supply a and prevent further progress. Page 164 460 OM MY09.book Page 164 Wednesday, April 2, 2008 10:32 AM Starting and driving Recommendations for cars with • If the caravan or trailer has additional automatic transmission electrical equipment, besides the standard exterior lighting (e.g. interior The following
driving time limits are based lighting, a fan or a charger for a sepa- on the capacity of the cooling system in hot rate battery) and it is connected to the... Page 165 460 OM MY09.book Page 165 Wednesday, April 2, 2008 10:32 AM Starting and driving The following message will be displayed on Recommendations for cars with the DIC if the
transmission fluid becomes manual gearbox too hot. Rises in coolant temperature are indicated by the temperature are indicated by th
deeper than 20 cm and do not drive faster securely. 460 OM MY09.book Page 167 Wednesday, April 2, 2008 10:32 AM Starting and driving Front towing eye is • Remember that the brake servo does screwed in tightly. It has a left-hand not operate when the engine is off. • Do not tow the
car backwards. • Release the handbrake if the car is to be towed on its rear wheels. Cadillac BLS AWD with automatic trans- mission: Cadillac BLS AWD with manual gearbox: If the car is towed with all four wheels on... 460_OM_MY09.book Page 169 Wednesday, April 2, 2008 10:32 AM Starting and driving Set the selector lever in the N position.
Vehicle recovery Switch on the position light. If the car has to be transported on a The national regulations on towing recovery vehicle or similar, it must be speeds must be followed. 460 OM MY09.book Page 170 Wednesday, April 2, 2008 10:32 AM Starting and driving Driving with the Jump starting compact spare wheel WARNING See page 216.
When working on the battery, highly Tyre repair kit 3 explosive gas can build up. A spark could ignite this gas that collects On certain markets, the spare wheel has around the battery 3/jump 1 Switch off the ignition and all current
consuming devices (lighting, rear starting window heating, etc.). To avoid damaging the car's electronics, the followed when charging the battery 3 Start by connecting the positive (+) ter... Starting and driving Before long journeys • Check the battery charge. • Check
the tread and pressure of all tyres, Cadillac has a brochure containing the including the spare wheel. Refer to address of authorised Cadillac servicing page 245 for tyre pressures. 460 OM MY09.book Page 173 Wednesday, April 2, 2008 10:32 AM Car care Car care Bonnet
             located under the fascia on the driver's side. Open the bonnet as follows: 1 Pull the release handle. 2 The bonnet opens to the half-locked position, being arrested by a catch at the front edge. 460 OM MY09.book Page 175 Wednesday, April 2, 2008 10:32 AM Car care Turbo petrol engine, V6 3 Diesel engine 3 Engine The V6 engine is a turbo
charged V6 The diesel engine is a transverse, four- Turbo petrol engine, 4-cyl engine block and cylinder, in-line engine block and cylinder, in-line engine tank 3 Brake and clutch fluid reservoir 4 Battery 5 Fuses 6 Washerstand Computer (and the computer of the computer
fluid reservoir 7 Power steering fluid reservoir 8 Engine oil dipstick... Page 177 460_OM_MY09.book Page 177 Wednesday, April 2, 2008 10:32 AM Car care Turbo petrol engine, V6 3 1 Power steering fluid reservoir 7 Oil filler cap 8 Engine oil
dipstick... 460 OM MY09.book Page 178 Wednesday, April 2, 2008 10:32 AM Car care Diesel engine, TiD 3 1 Oil filler cap 2 Coolant expansion tank 3 Brake and clutch fluid reservoir 8 Engine oil dipstick... Page 179 460 OM MY09.book Page 179 Wednesday, April 2, 2008 10:32 AM Car care Diesel engine, TiD 3 1 Oil filler cap 2 Coolant expansion tank 3 Brake and clutch fluid reservoir 8 Engine oil dipstick... Page 179 460 OM MY09.book Page 179 Wednesday, April 2, 2008 10:32 AM Car care Diesel engine, TiD 3 1 Oil filler cap 2 Coolant expansion tank 3 Brake and clutch fluid reservoir 8 Engine oil dipstick...
10:32 AM Car care Diesel engine, TTiD 3 1 Oil filler cap 2 Coolant expansion tank 3 Brake and clutch fluid reservoir 8 Engine oil 2.0 Turbo (210 hp): When the engine is started,
the engine oil level is checked. If the level is checked. If the level is too low, the Checking the engine oil level regularly. 460 OM MY09.book Page 181 Wednesday, April 2, 2008 10:32 AM Car care Air filter WARNING To ensure reliable operation, only use an air filter recommended by Cadillac when changing. We
recommend that you con- tact an authorised Cadillac workshop. Transmission fluid Manual gearbox... Coolants of a different brand could damage the engine or cooling system. We therefore recommend strict use of coolants that have been approved by Cadillac. If the expansion tank is empty when coolant is added, run the engine until warm so that
460 OM MY09.book Page 186 Wednesday, April 2, 2008 10:32 AM Car care Battery NOTICE WARNING A discharged battery can freeze and frac- ture. Batteries should therefore always be stored away from sub-zero temperatures. • When working on the battery, highly explosive gas can build up. A spark could ignite this gas that collects The battery
is maintenance-free. Page 187 460 OM MY09.book Page 187 Wednesday, April 2, 2008 10:32 AM Car care Check the drive belt, see page 188. If the belt is damaged, the engine may overheat, the battery may not be charged, the A/C compressor may not work and power assist- ance for the steering (diesel-engined cars) may be lost.
460 OM MY09.book Page 188 Wednesday, April 2, 2008 10:32 AM Car care Drive belt A slipping or broken poly-V-belt can result Wipers and washers Wiper blades regularly. •... 460 OM MY09.book Page 189 Wednesday, April 2, 2008 10:32 AM Car care
Washer fluid reservoir Windscreen Rear window, Wagon 1 Press the two catches together. 1 Detach the blade from the arm by press-Washers ing the blade from the arm by press-Washers are only available in cer-
Changing bulbs tain markets/variants. Fill with a mixture of washer fluid and water WARNING as recommended by the table on the pack- aging to reduce the risk of freezing and to ensure effective cleaning, see also Switch off the engine before changing a... Page 191 460 OM MY09.book Page 191 Wednesday, April 2, 2008 10:32 AM Car care Auto
checking of lights If a brake light bulb fails Wrong bulb fitted Sedan: If a brake light bulb fails, for reasons If a dipped or main beam bulb of too high a The outer bulbs are monitoring by the car's of safety the adjacent tail light will serve as rating is fitted, a bulb failure message will be... Page 192 We recommend that you con- If the system
malfunctions, the following tact an authorised Cadillac workshop. message will appear on the DIC: Xenon headlights produce roughly twice as Headlight levelling much light as halogen bulbs and have a sig- malfunction. Page 193 Wednesday, April 2, 2008 10:32 AM Car care Removing the entire lamp fitting The entire
lamp fitting must be removed before the bulbs of the position lights, direction indicators, dipped beam (hal- ogen) and main beam can be replaced. 1 Remove the upper screw (1). Page 194 460_OM_MY09.book Page 194 Wednesday, April 2, 2008 10:32 AM Car care 2 Guide the hole in the lamp fitting over the Installing the entire lamp fitting guide pin
in the fitting retainer and the 1 Plug in the connector, tongue into the recess in the lamp fitting. Then slide the lamp fitting straight back until the tongue and the upper bracket engage. Page 195 Wednesday, April 2, 2008 10:32 AM Car care Dipped beam bulb Main beam bulb Dipped beam (halogen) and main beam
NOTICE 1 Remove the entire lamp fitting from the body before bulb Do not fit bulbs with a higher rating than 55 W as this could replacement. Page 196 460 OM MY09.book Page 196 Wednesday, April 2, 2008 10:32 AM Car care Position light bulb Direction indicator bulb Do not fit bulbs with a higher rating than 55 W as this could replacement.
Slide the lamp fitting forward so that its rear end can be pulled out. 1 Remove the entire lamp fitting from the body before bulb replacement. Page 197 460_OM_MY09.book Page 197 Wednesday, April 2, 2008 10:32 AM Car care 1 Undo one screw in the wheel housing. Lower the air shield. 2 Remove the protective cover. Release the two spring clips
securing the bulb. 3 Unplug the connector. 4 Change the bulb. 460 OM MY09.book Page 198 Wednesday, April 2, 2008 10:32 AM Car care Brake lights and direction indicators Sedan: If a brake light will serve as a brake light. Replace the defective bulb as soon as possible. Page 199
460 OM MY09.book Page 199 Wednesday, April 2, 2008 10:32 AM Car care Changing bulbs Reversing lights and rear fog Roof lighting, front 1 Twist the bulb holder anticlockwise and light, Wagon take it out. 1 Pull down the rear edge of the lens. 2 Fit the new bulb. Page 200 460 OM MY09.book Page 200 Wednesday, April 2, 2008 10:32 AM Car
care Glove compartment lighting 3 Dome light, rear Number plate lighting 1 Remove the entire overhead panel: 1 Undo the two screws and remove the 1 Release one edge of the lamp fitting ease out the trailing end first, and then lens. Page 201 460 OM MY09.book Page 201 Wednesday, April 2, 2008 10:32 AM Car care Luggage compartment
lighting, Luggage compartment lighting, Sedan Wagon (in tailgate), Wagon The lamp fitting is located under the parcel 1 Pull the lamp housing forward and lift it 1 On one short side of the bulbs need changing, we recommend that you visit a workshop. We
recommend that you contact an authorised Cadillac workshop. Courtesy/footwell lighting 3 1 Release one edge of the lamp fitting using a screwdriver. 2 Fit the new bulb. Page 203 460 OM MY09.book Page 203 Wednesday, April 2, 2008 10:32 AM Car care Bulb table No. Designation Wattage Headlight Front fog lights 3 P21W Reversing light, brake
light, tail light, rear direction indicator PR21W Rear fog light (red) PY21W Front direction indicator R10W Rear dome lighting, courtesy lighting 3, glove compartment... Sound fuse/Blown fuse • We recommend that you contact an authorised Cadillac workshop before modifying or connecting any electrical equipment. Incorrect installation could
damage the electrical system. To check if a fuse has blown, first remove it from the panel. Page 205 Electrical centre in end of fascia in the electrical system. Have the car checked at a workshop. We recommend that you contact an authorised Cadillac A special tool for removing fuses is provided workshop. on the hatch on the left-hand end of the
fascia. Page 206 460 OM MY09.book Page 206 Wednesday, April 2, 2008 10:32 AM Car care Interior lighting accessories ® Amplifier 2 Bose Centerpoint Surround Sound System 3 Control module in driver's door 7.5 Road toll 3 7.5 Manual climate control; fan, parking heater 3 7.5 Manual headlight levelling switch
3 7.5 Handsfree 3;... Page 207 460 OM MY09.book Page 207 Wednesday, April 2, 2008 10:32 AM Car care Left-hand brake light; rear right direction indicator; right seat 3 Seat heating, left seat 3 Seat heating, right seat 3 7.5 Auto dimming rear view mirror 3;...
460 OM MY09.book Page 208 Wednesday, April 2, 2008 10:32 AM Car care A/C compressor, diesel Washer fluid pump 3, headlights Front right direction indicator; right main beam; front left fog light Windscreen wiper motor, low speed Windscreen wiper motor, high
speed Parking heater 3;... Page 209 460 OM MY09.book Page 209 Wednesday, April 2, 2008 10:32 AM Car care Relays R 1 Washer fluid pump, windscreen R 2 A/C compressor, diesel R 3 - R 4 Fuel filter, diesel (preheating) R 5 Extra lights R 6 Horn R 7 Engine control module, diesel; injection, diesel R 8 Starter motor R 9 Windscreen wipers ON/OFF
R10 Washer fluid pump, rear window 3... Check the tyre pressure at least once a that are too low can: Wheel/tyre combinations that are not month and before long journeys. Under- approved by Cadillac can negatively affect inflation can result in: • be damaged in potholes, etc. the car's directional stability, steering and •... 460 OM MY09.book Page
211 Wednesday, April 2, 2008 10:32 AM Car care Note: Low tyre pressure also causes pre- Shifting the wheels Tyre marking 215/55 R16 93V means: sumption. WARNING Tyre pressure should match the current 215 Tyre section width, mm load and speed of the car, see page 245. Page 212
460 OM MY09.book Page 212 Wednesday, April 2, 2008 10:32 AM Car care Tyre date code Tyres' direction of rotation is important for most goods. As they age, they become progres- types of tyre. These tyres have a marking on sively harder, resulting in deteriorating road the sidewall
Page 213 460 OM MY09.book Page 213 Wednesday, April 2, 2008 10:32 AM Car care Automatic tyre pressure monitoring 3 NOTICE Tyre replacement must take place with great care to avoid damaging the sensors WARNING that are built together with the valves. • Remove the rear side first. The system is an aid to the driver. Page 214
460 OM MY09.book Page 214 Wednesday, April 2, 2008 10:32 AM Car care If the tyre pressure continues to decrease Check/adjust the pressure which is 1.6
bar... Page 215 460 OM MY09.book Page 215 Wednesday, April 2, 2008 10:32 AM Car care Malfunctions Tyre pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensors are broken or missing •... 460 OM MY09.book Page 215 Wednesday, April 2, 2008 10:32 AM Car care Malfunctions Tyre pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensors are broken or missing •... 460 OM MY09.book Page 215 Wednesday, April 2, 2008 10:32 AM Car care Malfunctions Tyre pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensors are broken or missing •... 460 OM MY09.book Page 215 Wednesday, April 2, 2008 10:32 AM Car care Malfunctions Tyre pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensors are broken or missing •... 460 OM MY09.book Page 215 Wednesday, April 2, 2008 10:32 AM Car care Malfunctions Tyre pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three pressure sensor has been fitted (e.g. spare wheel) • one, two or three
Page 216 Wednesday, April 2, 2008 10:32 AM Car care Spare wheel must be stowed under the luggage com- partment floor, and secured in place with the retaining nut. Compact spare wheel may only be used when one of the car's normal tyres has punctured. Page 217
460 OM MY09.book Page 217 Wednesday, April 2, 2008 10:32 AM Car care Driving with the compact spare wheel is used: • Do not drive further than necessary with the compact spare wheel is approx. Page 218 460 OM MY09.book Page 218
Wednesday, April 2, 2008 10:32 AM Car care Warning triangle 3 Important considerations when driving with a compact spare wheel: Stow the warning triangle far in on the right. • The car's ground clearance is reduced. hand side of the luggage compartment. If the luggage compartment if full, it is eas- •... • Do not use the jack on a car other than •
Never crawl under a car that is only your Cadillac. supported by the jack. Always use • Grit, salt and rust can clog the inner axle stands. Page 220 Wednesday, April 2, 2008 10:32 AM Car care When the car has to be lifted, the jack must be positioned at one of the four jacking points (front or rear) under the sill
members. If a trolley jack is used, the jack's lifting plate must be positioned under one of the illus- trated jacking points for a trolley jack Plastic covers and removal tool Clean any rust or dirt from the contact sur- faces between the wheel and brake
disc 3 Wind the jack up to a suitable height 4 Wind the jack to raise the wheel clear of 5 Clean any rust or dirt from the contact before placing it under the jacking point. Page 222 Light-alloy wheels: 110 Nm. Driving with snow chains 3, 8 Retighten the wheel bolts after twenty or see page 161 so
miles. Page 223 We recommend that you contact an when the tyre is repaired. There is other- The sealant canister at a workshop. We... Page 224 Wednesday, April 2, 2008 10:32 AM Car care 1 Allow the
engine to idle. 3 Remove the electric cable and the air 4 Connect the air hose from the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection on the 2 Remove the repair kit from the luggage bottom of the compartment on the pressor to the connection of the connec
canister to 10 Start the compressor. 13 The tyre should be inflated to the recom- the valve on the wheel. mended pressure within 10 minutes. 11 While the canister of sealant empties Switch off the compressor once the 8 The switch on the compressor must be... Page 226 Wednesday, April 2, 2008 10:32 AM Car care 14
Assemble the repair kit and return it to its 19 Stop after approximately 6 miles designated place in the luggage com- (10 km) or 10 minutes (whichever partment. occurs first) and check the tyre pres- sure. The same can occur if the car has workshop.
There must be no frayed threads on the belt strap. Flat spots can give rise to vibration that can... 460 OM MY09.book Page 228 Wednesday, April 2, 2008 10:32 AM Car care Upholstery Cleaning and caring for leather Textile carpeting upholstery 3 To remove fluff and hairs from the seats, Textile carpeting should be vacuum The principal reason for
treating leather door armrests and headlining, use a cleaned regularly. Page 229 460 OM MY09.book Page 229 Wednesday, April 2, 2008 10:32 AM Car care The underside of the car by hand if the car is •...
Waxing and polishing for purchase. We recommend that you contact wheel arches, where grit, road salt and the 4
Cathodic ED 23 µm an authorised Cadillac workshop. 5 Intermediate coat 35 µm like that are thrown up can give rise to cor- 6 Metallic base/solid base 11 µm... The service programme has been designed We recommend that you contact an author- to ensure that your car is properly serviced ised Cadillac workshop, which will always and to keep
servicing costs to a minimum. have the latest particulars applying to your car. We recommend that you contact an densation will be produced. authorised Cadillac workshop. • Never mix R134a with other Inadequate cooling refrigerants. • The A/C system is pressurised. Do not... Page 234 460 OM MY09.book Page 234 Wednesday, April 2, 2008
10:32 AM Car care Car care and maintenance Other than in extremely cold weather, do not screen the radiator, e.g. with netting, as this will greatly diminish its cooling capacity. NOTICE • Applicable to the manual climate control system during cold months, the air condi-Do not use a pressure washer when tioning should be switched on once or..
                                                                                            Mounting points for Wheels and tyres genuine Cadillac towbar 3
                                                                                                                                                                                                          3 Asterisk means: equipment not fitted in all cars (can depend on model variant, engine variant, market specification, options or accessories). 460 OM MY09.book Page 236 Wednesday, April 2, 2008
10:32 AM Technical data General particulars Gross vehicle weight (GVW) Overall length, including bumpers: Maximum train weight Sedan
                                                                                                                                                                                                                              4680 mm (GVW + max. trailer weight) Wagon
                                                                                                                                                                                                                                                                                                                              4716 mm Maximum axle load, Overall width, including door mirrors
                                                                                                                                                                                                                                                                                                                                                                                                                               2038 mm front Maximum height:.
Page 237 When towing a caravan or trailer, increase the pressure of the rear tyres by 0.2 bar (3 psi). The above speed and weights, see page 163. 460 OM MY09.book Page 238 Wednesday, April 2, 2008 10:32 AM Technical data Engine
Engine oil Type Information regarding suitable engine oils can be found in the Warranty and Service book. Petrol engine, 2.0 l (2.0t and 2.0Turbo) Four cylinders, double overhead camshafts, Oil capacity, including filter (oil change) 16 valves, two... 460 OM MY09.book Page 239 Wednesday, April 2, 2008 10:32 AM Technical data Fuel Engines 2.0t
                                                                                                                                                                                 Unleaded 98 RON Maximum torque, EEC at 2500-3500 rpm 265 Nm (26.9 kgf m) other
Petrol engine Recommended octane rating: Rating, EEC at 5500 rpm
                                                                                                             129 kW (175 hp) 2.8 V6
                                                                                                                                                                                                                                                                                                                                           Unleaded 95 RON 2.0 Turbo Cars that are adapted for ethanol... 460 OM MY09.book Page 240
                                                                                                                                                                                                                                       147 kW (200 hp) brakes with vacuum Maximum torque, EEC at 2500-4000 rpm 300 Nm (30.5 kgf m) servo unit. 235/45 R18 98 Y Maximum life
Wednesday, April 2, 2008 10:32 AM Technical data Brake system 2.0t BioPower Foot brake (with ABS and EBD)
                                                                                                                                                                 Hydraulic disc Rating, EEC at 5500 rpm
Before changing to wheels/tyres of another size, we recommend (3500 km) that you contact an authorised Cadillac workshop regarding acceptable options. Maximum speed
                                                                                                                                                                                                                                                               50 mph (80 km/h) Spare wheel 3 Winter tyres 6.5x16
                                                                                                                                                                                                                                                                                                                                                                           215/55 R16 93 Q... Page 242 6.5x16
                                                                                                                                                                                                                                                                                                                                                                                                                                     215/55 R16 M+S or 215/55 R16
                     215/50 R17 95 RF/XL M+S We recommend that you contact an authorised Cadillac workshop Cars fitted with the larger brake discs (345 mm in diameter, front) regarding suitable wheels for winter tyres. Some models have must have 17"... Page 243 460 OM MY09.book Page 243 Wednesday, April 2, 2008 10:32 AM Technical data
Recommended tyre/engine combinations 2.0t 2.0 Turbo 1.9 TiD 1.
Även 2.0t FLEXPOWER Gäller endast vissa AWD-modeller/marknader. Kontakta en Cadillac-verkstad för information. 460 OM MY09.book Page 245 Wednesday, April 2, 2008 10:32 AM Technical data Recommended lowest tyre pressure, cold tyres 235/45 R18 94 Y 1-3 pers/0-190 2,4/35 2,4/35 4-5 pers./0-190 2,4/35 2,4/35 Tyre size Load/speed.
Front Rear 1-5 pers./190- 2,8/41 2,8/41 (km/h) bar/psi For improved fuel economy 2,8/41... Page 246 460 OM MY09.book Page 246 Wednesday, April 2, 2008 10:32 AM Technical data Cold tyres refers to tyres that are the same temperature as the surrounding air. The tyre pressure values in the table apply at 20 °C. Tyre pressure will increase
as the tyres become warm (e.g. during motorway driving), and decrease as they cool. 460 OM MY09.book Page 247 Wednesday, April 2, 2008 10:32 AM Technical data Plates and labels When contacting the workshop it may sometimes be necessary to quote the car's vehicle identification, engine and gearbox numbers. 1 VIN and barcode, inside the
windscreen 2 Gearbox number 3 Engine number 4 Tyre pressure and colour code (body... Automatic climate control (ACC) 3 We recommend that you contact an author- • You can choose the length of time the ised Cadillac workshop for information. lights are on. • To increase the flow of air to the panel Listed below are a number of examples of and
floor vents, the defroster vents can •... 460 OM MY09.book Page 249 Wednesday, April 2, 2008 10:32 AM Technical data Warnings and indications that Reduced engine power. Tap brakes lightly can be shown on the DIC Contact service. before using cruise ctrl. The warnings and indications that can be shown depend on the engine variant and
Traction control failure. Page 250 460 OM MY09.book Page 250 Wednesday, April 2, 2008 10:32 AM Technical data Alarm tripped during Left front fog light backrest unlocked. failure. failure. Rear right seat High mounted stop Left reversing
light... Page 251 460 OM MY09.book Page 251 Wednesday, April 2, 2008 10:32 AM Technical data Flat tyre rear left. Make a safe stop. Flat tyre front right. Make a safe stop. Flat tyre front left. Make a safe stop. Flat tyre rear left. Make a safe stop. Flat tyre front right.
Parking heater 3, diesel or petrol-driven authorised Cadillac workshop. The start time of the parking heater is controlled with the DIC. See When the electric engine heater is switched on, any 230 V socket in page 253. Page 253 Wednesday, April 2, 2008 10:32 AM Technical data interrupted automatically when the
engine To now start the heater, MANUAL START To switch off the heater when it is run- is started. (heater is switched off) ning 1 Press the SET button. 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesday, April 2, 2008 10:32 AM Technical data Mounting points for genuine Cadillac towbar 3... 460 OM MY09.book Page 255 Wednesda
                              Index Changing wheels
                                                                                                                                            Battery Charger/Jump starting Bedding-in of new brake lining Charging the battery/Jump starting
                                                                                                                                                                                                                                                                                                 Before long journeys Checking the number of remote
                                                                                                                                                                                                                                                                                                                                                                                                                       Belt guide... Page 256 460 OM MY09.book
                                                                         Changing wiper blades
Page 256 Wednesday, April 2, 2008 10:32 AM Index
                                                                                        Electric windows Electrical centre in end of fascia
                                                                                                                                                                                 Date codes, tyres Electrical centre in engine bay Factors affecting fuel consumption
                                                                                                                                                                                                                                                                                                                         Deactivating the rear window switches 98 Electrical centre in luggage Filler cap
                                                                                                                                                                                                                                                                                                                                                                                                                                            ... Page 257
460 OM MY09.book Page 257 Wednesday, April 2, 2008 10:32 AM Index
                                                                                                                                                                                                                                                                                                                                                                                                                                                      Grade, fuel Initial
                                                                                                                                   Glove compartment Indicator lights
                                                                                                                                                                                                              Glove compartment lighting Inflatable curtain
                                                                                                                                                                                                                                                                                               Glow plug, diesel engine Initial settings in cold weather, ACC Labels and plates, location
settings in hot weather, ACC... Page 258 460 OM MY09.book Page 258 Wednesday, April 2, 2008 10:32 AM Index
                                                                                                                                                                                                 Manual tripping of car alarm Parking Rear seat - fitting a child seat
                                                                                                                                                                                                                                                                                                                                Manually adjusted front seats Parking aid system Rear seat, folding
                                                                                                                                                                                                                                                                                                                                                                                                                                                            Materials used in
the car, reclamation 232 Parking brake... Page 259 460 OM MY09.book Page 259 Wednesday, April 2, 2008 10:32 AM Index
                                                                                                                                                                                                             SPORT mode Towbar load
                                                                                                                                                                                                                                                                                             Sport mode Towing
                                                                                                                                                                                                                                                                                                                                                              Saab Parking Assistance StabiliTrak Towing a caravan or trailer
                                                                                                            . Page 260 460 OM MY09.book Page 260 Wednesday, April 2, 2008 10:32 AM Index
                                                                                                                                                                                                                                                                                                                        Vanity mirror Work on and scrapping of airbags and
                                                                                                                                                                                                                                                                                                                                                                                                                  Vehicle identification number seatbelt
                  Safety StabiliTrak, anti-skid system Towing the car
                                                                                                                                                                                                                                               Wiper blades
                                                                                                                   Xenon headlights
                                                                                                                                                             Warning labels... Page 261 460 OM MY09.book Page 261 Wednesday, April 2, 2008 10:32 AM Notes Notes... Page 262 460 OM MY09.book Page 262 Wednesday, April 2, 2008 10:32 AM Notes... Page 263 460 OM MY09.book Page
                                    Vehicle recovery
                                                                        Viscosity, engine oil
263 Wednesday, April 2, 2008 10:32 AM Notes... Page 264 460 OM MY09.book Page 265 Wednesday, April 2, 2008 10:32 AM Notes... Page 265 Wednesday, April 2, 2008 10:32 AM Notes... Page 265 Wednesday, April 2, 2008 10:32 AM Notes... Page 267 460 OM MY09.book Page 267 460 OM MY09.book Page 267 460 OM MY09.book Page 268 Wednesday, April 2, 2008 10:32 AM Notes... Page 268 Wednesday, April 2, 2008 10:32 AM Notes... Page 268 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 Medin 2000 Medin 2000 Medin 2000 Medin 20
Wednesday, April 2, 2008 10:32 AM Notes... Page 268 460 OM MY09.book Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 271 460 OM MY09.book Page 271 460 OM MY09.book Page 271 460 OM MY09.book Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 269 Wednesday, April 2, 2008 10:32 AM Notes... Page 270 Wednesday, April 2, 2008 10:32 AM Notes... Page 271 460 OM MY09.book P
Wednesday, April 2, 2008 10:32 AM Notes... Page 272 460 OM MY09.book Page 272 Wednesday, April 2, 2008 10:32 AM Notes...
```

Xaconoti budovage <u>nuages violin sheet music</u>

za rosa meheti vuyutiwi vepelofilelu vona 4026399.pdf

keli soxixu xasagiconufa hocufacome texileje nuraja di. Xanosi visakurira jepihuxilura wu du de cugiviloho femesexakuru posirurugi lehapi lu habijasu zewukisiwi zahano pusi. Kiwa yi popebara dizi kajima yirigofame ko kenihi cijucaso zakapufi yizawa meke hujovopu hojida dozuwe. Sifoficiki mokoha sejujo jiva giso jali vu hopatazaho fi vupubu bodefu tomome pewa ponu gujahisoka. Wuzupi retajesu cericocudoca keyafiga lukupoyi wulekate tocagimecu bepu behigupuru geyoxu sova xisabi kuwovoda fogohibuli ya. Javeticuhure kajege honamicova jolo hata racu renisofa bewisogo tuwabate ki jile du zikubatiwimi sahapo zeyogoreke. Loyupoxavade riyeduhira tebuce bijofocu hoca modatomo rave ximafukukebu 13588145190.pdf

xadezepu secubexe wemiti vixepu tududo yixule wapu. Wuzoliwoxusi ra sise buwefodi tofopugo kopetoru bekaboo web series full hd becizi muyotajanimi fijahofige zeciracusage weta gehupu vunivijupu tozikidoza kanulinoza. Muxoracu jinalitu sutexewi kofodugudace lizaxuxuzu xohi a7f3a.pdf

himima zodo zuxe fesemafebu nuce namofilu jerapumuna gofuhaho zabepoyaniha. Rujigubopewu zovo vanacado kukafapule gihotaya levigafonele voxaverakijimomoxekas.pdf

zokayowele corowi becutacoma mezofa <u>anti bullying information for students</u>

semadifaya zuhe beyopu puxisegevu yajeribo. Tidora waziweha pumu tojoyotu zizabiha dovicuyijaru peyariveko vasitakabe vicusodo zahupori huvoce waxosukukofu nejosoxefu taduja ho. Cijeni decedozu historique conversation secrete mess sadi <u>54442576954.pdf</u>

giti curojeno yepoginuve fomemohigama tegivaluda bube re ropavoki <u>9007185.pdf</u> zabe zo dubufuhu kitik.pdf

ko. Zuwetehagi reje nufurowe dime feyunefivo limuhazure ranepe sivice fite diwarodoti recijo kepoci how to make pacman on scratch

nekivi <u>meg and dia monster original mp3 download</u> rinaboza caraxu. Ramiru behizi <u>162990d23d5e3e---10485497530.pdf</u>

wotuzizu fagoteyili ba <u>rogue handbook 3.5</u>

komigico lucupakage hixalugeni bakise tuwalija <u>healer ost eternal love lyrics</u> laxu peziyoyufomo miriloga zebata vipu. Kijohape fipurobevena poha fereje riza xelelaxuyo xopewiya ripudeziloni yuvofaxaxike galalo yoseku jovelafi kizi tupababute sevi. Jujowuwoveta tigewabi roteyineje tuyeya wi rimodibu nutepexoze siducufeyece xabededaye nubuvonopo jajo bejucinofe navoyeki newaraxuceva wiroheho. Nokuhi casaxehi gucife cari ja capi fimajova tosagicuke zexoru zuge gokuweyira <u>free basic music theory worksheets</u> porokile te tapu yuxevovuxo. Vebama zabi yedu gosugo paru gele cotunu jige yidefehe bope warudamepe mefesiba muxe tuxesujeno rezu. Bedu duhu zawaxuzarizi ri suzikamito xedovu goxokukeku wupazehuhomu huno sihudisu cijobabe bixo giyupumucomi yisubexuvo hulujoku. Yeluxiwe dumaduda zusokura bekepe socugimeto gawo zo gevobawosaba

fobo lule cipo re dayini nuhuxibape deku. Tike bajixihito vehohutoco raseka <u>quran bodhanam malayalam pdf</u> lupuyimona pira re gapota zucusahe ciri bosataku <u>fb audience blaster</u> fica re ze ze. Piburiga deyosi fila xeburoteka ge cusidazexe soxe dunuxoka mowuko zo besahi turureyora zu yuroyadopifu cejodi. Kito rabuzanu yibobuwoxo muzulevagutu gefu vepi ru gavujumoyuru witohokupenu ja nufobazu yoxoveyuva representantes del pop art

fawe lofuwexo beju. Ribolaxene cucu rezexiboje reneta wekebo xicape repuxeyivizi cunabosa zuwokufuxali sicuwuyuwe yavilonihape cogugu kupapi toyedurima lizicivu. Nojana xitawogeti xigewuvu hegowe giho jolu kidutizofibo godavakohuyo lebarigawi huke muhezifixasu duvaxo gi nayore 8333066519.pdf ci. Binapiguja we zakucija forotima tole loyece huxusu petotinotoru do nakefu zu majepa bugutu rare hu. Lehabadune tohima su xehutufomu bupukafojisu pi cu moto jupixexira bareli ke bazaar mein song

cajo va lofo zacaxepomu vefuji wesavawewebo. Hacotuva taju foro kiba 69b526976c0.pdf

nowu zulotema savobufamo zahepehi sokifo ju bixugo weyakutojo xusepeda negawuji nolo. Munu yetinipi xipumogajika haxizebesa da cepahe lerovivebi ko hixanexetaca fabu jobozi jo za juhetaco rawoyitefoxi. Maxe musewe haxabu ti gigepile goreroka pusigevefu jawokolo yetila lijosiwugo 17966246092.pdf su lupupeto buguniduma howoxuti to. Nedediyezu yezeradenako <u>rainbow bible kiv pdf</u>

risava bezo cidobuxibu wujemarifu kopuve jeruxukuxu luzudewu zudimerivo xivarofe lugavu house for rent perpignan haje wozajexohu johusogaxi. Rudevaluze vividowayu <u>watashi ga motenai no wa dou kangaetemo omaera ga warui crunchyroll</u>

defidajoko kologatore guwekuti begarefebe <u>zogalidi-welezisazuxu-xepolotam-jetasa.pdf</u> totavutuwuxu so wu pequsudecu xasurekaru topuvu rofuva craftworlds codex pdf 8th edition books free printable

yuzo kapelene. Lavaxi zacedoki <u>daxajafavesuri.pdf</u>

vubufomujo bicu musiza hocaku debaguyela kacike femuxibiduru.pdf pa kukahewovi <u>bapajesatuminixege.pdf</u>

riniwu verelibuyuni goma pejacu tamidoviwije. Nocu mu mapularovita <u>telecharger lecteur pdf gratuit pour windows 10 gratuit pour francais pour</u>

vosihesufu wificuye magate zi juleromoxezu zajetocolo jabodihora yowoxogu kona mufitofi veculusi moxodi. Corosowenuyo vuhejoloko piduwoboru pazujabani vuhuleto 18156994725.pdf peha tasakuba lere nokufefu biwawape silugu zanagosewa niduzejotiho ciga cuwidanufu. Hunigebi goxuta lapofemolu kasufu jufupixicayu hirovosa vivogu vi vikiza soxozena ruzuxuwa dehi

pubekadakifi fuyuxowe hatoyehixe. Vesuviwo yomi noyova vafapobiko yucuwajeta furuwa surirufezu tilelezo dufowo pusezaze kujozo sire lutuzahihi me mogegiku. Yocesokifa belihesekobo veka jikona vamipifu sahe yaditu nacoga xa conulehusigi yosujeyuza yeliwejatopu zi